


















# CASSIOPEIA 20' X 20' KIT

Thank you for your purchase of Orbital Expo Truss Extreme. These instructions show how to erect the kit you purchased. The color coded section will help identify the location of each part.




 <p><b>6-WAY JUNCTION BOX</b> <b>23</b></p>	 <p><b>45 CURVED TRUSS SECTION</b> <b>0</b></p>	 <p><b>ADJUSTABLE SCALLOP TABLETOP</b> <b>0</b></p>	 <p><b>INTERNAL SHELVES</b></p> <p>24" <b>0</b> 36" <b>0</b> 46" <b>0</b></p>
 <p><b>24" LONG TRUSS SECTION</b> <b>6</b></p>	 <p><b>90 CURVED TRUSS SECTION</b> <b>12</b></p>	 <p><b>50 WATT CHROME SPOTLIGHT</b> <b>0</b></p>	 <p><b>ORBITAL FRATE CASE (OCF)</b> <b>1</b></p>
 <p><b>36" LONG TRUSS SECTION</b> <b>12</b></p>	 <p><b>UNIVERSAL CONNECTOR</b> <b>4</b></p>	 <p><b>LONG CONNECTOR</b> <b>244</b></p>	 <p><b>ORBITAL FRATE CASE (OCO)</b> <b>2</b></p>
 <p><b>46" LONG TRUSS SECTION</b> <b>18</b></p>	 <p><b>ADJUSTABLE TABLETOP</b> <b>4</b></p>	 <p><b>SHORT CONNECTOR</b> <b>92</b></p>	 <p><b>SCREW DRIVER</b> <b>4</b></p>


Each Orbital Expo Truss Extreme kit has been carefully designed and developed to be stable and safe. Consult with your dealer for load bearing specifications. The manufacturers of Orbital Expo Truss Extreme will not be held responsible or accountable for damage or injury caused by exceeding guidelines or through wrongful/incorrect use of the system.



# CASSIOPEIA 20' X 20' KIT




## Color Coded Components



PICTURE ONLY REFERENCE ONE SECTION OF THE KIT. THE OTHER SECTION IS SIMILAR, SEE NEXT PAGE FOR FRONT TOP AND RIGHT SIDE VIEW.



# CASSIOPEIA 20' X 20' KIT



## Color Coded Components

